

Congratulations on the purchase of your NEW FIREWALL PAD! It is made of vacuum formed ABS plastic and resists the rigor of any climate hot or cold. It has a leather grained finish to resemble the original equipment. An original firewall pad was used as a template for the size and hole locations.

INSTALLATION: Remove all electrical/mechanical controls from the firewall. Remove the old firewall. Be sure to save the felt pad and soundboard if your vehicle came equipped this way. Re-install the old felt and soundboard and position the NEW firewall pad against the inside of the firewall. Use a small Phillips screwdriver to poke through the mounting holes and position the firewall pad. Insert the necessary hardware to secure the firewall pad to the firewall. The assistance of a friend may be useful at this stage. Once the firewall has been securely fastened to the firewall, re-install the electrical/mechanical controls.

TIP: If you have difficulty passing the electrical/mechanical components through the firewall pad and firewall in the mounted position remove the firewall pad and pass the components (that are giving you trouble) through the firewall pad and then finish the installation process.

CARE: This ABS material resist temperatures up to 239 degrees. It may be cleaned by using a damp cloth. For further protection you may want to use a product that provides ultraviolet protection.

MODIFICATIONS: Additional holes can be drilled into the firewall pad by using metal drill bits.

DO NOT USE DRILL BITS INTENDED FOR WOOD PRODUCTS.

Use a hole saw for large holes to get the best results. After the hole has been cut, roll up a piece of fine/medium sand paper or round file and finish the edges for a clean appearance. If the contour of the outside edges of the firewall pad needs to be changed, use a medium grit sand paper on a sanding block.

TAKE IT SLOW-YOU CAN TAKE OFF A LOT OF MATERIAL WITH JUST A FEW STROKES.

The firewall pad has been manufactured for your specific year and model. However, we have discovered that there may be some variation between models in any given year.

If you find this firewall pad is NOT correct for your vehicle **DO NOT ALTER IT IN ANY WAY!** We will have the correct firewall pad made for you. Please let us know of any problems so we can correct the problem immediately.

NO REFUNDS ON ANY FIREWALL PAD MODIFIED OR ALTERED IN ANY WAY. FIREWALL PADS MUST BE IN LIKE NEW CONDITION TO RECEIVE A REFUND!