



INS_009

- 1) Take the hood lacing out of your vehicle.
- 2) Fit the lacing to the contour of radiator shell or cowl by bending the lacing to fit the surface.
- 3) Bend one end of the wire at a right angle to establish the position for fitting.
- 4) After fitting the contour, trim the other end allowing 1/2-5/8 of an inch of center wire to bend over the final fit.

BE VERY CAREFULL OT TO SCORE THE WIRE INSERT! IT COULD CAUSE BREAKAGE UPON BENDING!

- 5) Once you are positive that the installation is final - Bend both ends at right angles just enough to firmly fit the lacing against the surface.

NOTE: For a perfect fit, in addition to the original attachment described, contact cement may be used to achieve a perfectly flat fit.