



WINDOW AND VENT CRANK KNOB INSTRUCTION

1. Using vise grips or bench clamp, break knob free of retaining pin.
2. Heat water to 120 degrees and immerse knob in water for 1-2 minutes or until plastic is slightly softened.
3. Put new retaining pin through handle and firmly push knob onto pin.