



INST#38

Suggestions To Install Sliding Quarter Windows Weatherstrip (As Original)

- Materials needed:**
1. A pair, sliding window rubber (supplied)
 2. A strip of felt (supplied)
 3. A thin metal strip approx. 1/64" thick x 9/16" wide x 18 1/2" long (NOT INCLUDED)

- Step 1. Attach felt to metal strip with an adhesive.**
2. Secure felt and metal strip to the car, with rubber underneath, with small metal screws. The felt and metal strip must be positioned in the center of the rubber, as shown in fig. 3, so the glass will meet the felt when closed.

