

Pushrod cover installation is best accomplished with the distributor removed. The breather canister nearly always will touch the lower pushrod cover fin. Very gently dimple the canister with a light hammer.

Tighted the pushrod cover screws progressively; not all at once. And **DON'T OVER- TIGHTEN.** To do so only bends the cover. Be gentle.