

HEADLINER SPECIAL INSTRUCTIONS
FOR 39-46 TRUCKS

THE HEADLINER WAS FASTENED TO THE TOP OF THE FLANGE ON THE FRONT HEADER PANEL WITH SCREWS AND SPECIAL CLIPS.

THESE CLIPS ARE NOT AVAILABLE; BUT WE HAVE SUPPLIED A REPLACEMENT TYPE CLIP THAT WILL WORK.

THESE CLIPS ALSO MAY BE USED TO FIX STRIPPED THREADS IN THE SHEET METAL FLANGES.

THE SIDES, BACK AND 40-46 FRONT WERE ALL THE SAME WITH A RETAINER STRIP TO FACE THE FLANGE.

WHEN INSTALLING A 1939 DO NOT DO STEP #1 UNTIL THE HEADLINER IS IN AND YOU CAN SCRIBE TO FIT THE DOOR OPENING.

IN STEP #2, ONLY DRILL THE CENTER FRONT AND BACK HOLES.

