

INSTRUCTION SHEET .

#1HS-598991-2

PART # 598991-2 39-46 TRUCK WIPER ARMS:

THESE WIPER ARMS ARE CORRECT AND ORIGINAL EQUIPMENT FOR 1939 TO 1946 CHEVROLET TRUCKS. HOWEVER, THE ARMS ON YOUR TRUCK MAY HAVE BEEN REPLACED BY THE ARMS USED ON THE 41-48 PASSENGER CAR AT SOME TIME IN THE PAST. THIS SEEMS TO BE FAIRLY COMMON. IF THIS HAS BEEN DONE ON YOUR TRUCK, THE POST THAT THE ARM ATTACHES TO WILL HAVE AN ADAPTOR ATTACHED TO THE END AND SECURED WITH A PIN. THIS CONVERSION ADAPTOR CAN BE REMOVED BY DRIVING OUT THE SECURING PIN AND PULLING OFF THE ADAPTOR.

TO INSTALL THE ORIGINAL STYLE WIPER ARMS:

1. REMOVE THE CHROME COVER FROM THE WIPER ARM.
2. PUSH THE HOOKED END OF THE WIPER ARM THROUGH THE HOLE AT THE END OF THE WIPER MOTOR POST.
3. WITH THE SLOT AT THE NARROW END OF THE CHROME COVER PUSHED ONTO THE WIPER ARM, SLIDE THE TENSION SPRING BACK UP TO THE TOP AND CLIP THE WIDE END OF THE COVER OVER THE WIPER MOTOR POST SO THAT THE SWIVEL "U" CLIP IS HELD BY THE "V" SHAPED GROOVE OF THE WIPER MOTOR POST.