



Cut or grind clearances in lip of headlight housing. If ground or cut correctly you can insert the assembled buckets (trim & lens removed) in through the opening. Mark and make sure mounting holes on outer bucket line up with 3 holes and drill in lip of housing.