

Installation Instructions

1. **Disconnect Battery.** **Do not skip this step.** Also, do not try to “test” the LED array by connecting the leads directly to your battery. Permanent damage will occur to the LED array if you fail to heed these steps.
2. Remove the current taillight assemblies from your car.
3. Position the supplied body seal on the car.
4. Remove the stainless steel nuts and washers from the LED taillight assembly and install into the fender.
5. Reinstall the stainless steel washers and nuts. Position the taillight for the best fit and tighten the nut using a 3/8” socket. **Do not overtighten!**
6. **Wiring.** Using the supplied connectors, connect the **wire from the taillight circuit to the black wire** on the supplied harness. To use the connector: put both wires in a separate hole, unstripped. Holding the wires as far in as possible, squeeze the connector with pliers. Some “goo” may come out of the connector. This “goo” ensures a watertight connection. . Repeat by connecting the wire from the **brake light circuit on your car to the red wire on the supplied harness.** The green wire is

connected to a good body ground.

7. Repeat for the other side.
8. Reconnect the battery.
9. Test both STOP and taillight functions.
10. Enjoy!

Technical Notes

11. Turn Signal Flashers: If your car has a conventional bulb in the front parking light, your existing flasher should work. If you have an LED or no front parking light, you will need an electronic flasher. We have these available.
12. Normal operation of the LED array has two LEDs at full intensity and 12 LEDs at reduced intensity for the tail function. All 14 LEDs are at full intensity for both the stop and turn function.